



FORD AXODE / AXOD Installation Instructions

Rostra Precision Controls, 2519 Dana Dr., Laurinburg, NC 28352 800-782-3379 www.rostra.com

1. Remove old solenoid.
2. For AXOD applications, remove the bracket arms marked "A" by bending at the scores with a pair of pliers (**Fig. 1**). Install solenoid and tighten mounting bolts.
3. For AXODE applications, remove the bracket arms marked "B" by bending at the scores with a pair of pliers (**Fig. 1**). Assemble the AXODE port adaptor as shown (**Fig. 2**). Install solenoid and tighten mounting bolts.

